

DB-5 MKII


Install the "RangSet_V1.19.exe" software;

Connect the radio to the computer and start the software;

Set the communication port ("Setting" → "ComPort Select");

Read the radio data by clicking on the "Read" button;

Change the bandwidth limits using the drop-down menu:



136M-174M 400M-480M ▼

Send the data to the radio by clicking on the "Write" button (the radio will already work within the modified set band limits).

Now it is possible to do by means of the keyboard:

Close the two VHF / UHF bands:

- switch off the device;
- hold down the keys "P2" (the one under the PTT) + "*" and switch on at the same time.

Widen the two VHF / UHF bands:

- switch off the device;
- hold down the keys "1" + "7" and switch on at the same time.